IRONSIDE BRAKE PEDAL PAD

GENERAL

Kit Number

46959-07

Models

This kit fits 1980 and later Touring® and 1986 and later FL Softail® model motorcycles.

NOTE

A Service Manual for your model motorcycle is available from a Harley-Davidson Dealer.

Kit Contents

See Figure 1 and Table 1.

INSTALLATION

- Remove the previously installed brake pedal cover from the foot brake lever.
- See Figure 1. Obtain the mounting plate (7) from kit. Position the mounting plate over the brake pedal (A)

aligning raised area under plate with oval hole in brake pedal.

- Obtain the offset washer (2) from kit. Position washer under brake pedal and align the "offset" area of the washer so that it covers oval hole in brake pedal.
- 4. From top of mounting plate, install 5/16 inch flathead screw (1) through mounting plate (7), brake pedal (A) and offset washer (2).
- 5. From under brake pedal, install acorn nut (3) to secure mounting plate and offset washer to brake pedal. Tighten acorn nut to 25-29 ft-lbs (33-39 Nm).
- 6. Obtain brake pedal cover (5) and pedal tread (6) from kit.

 Align and insert tread (6) into the brake pedal cover.
- 7. From the side, slide the brake pedal cover assembly over the mounting plate (and pedal) and align the two holes in bottom of cover with two holes in mounting plate.
- 8. Obtain the two 10-24 screws (4) from kit. From under brake pedal (A), install screws through holes in mounting plate (7) and into pedal cover (5). Tighten screws to 20-22 inlbs (2.2-2.5 Nm).

-J04070 1 of 2

SERVICE PARTS




Figure 1. Service Parts: Brake Pedal Pad Kit

Table 1. Service Parts Table

Item	Description (Quantity)	Part Number
1	Screw, 5/16-18 x 7/8 inch w/lock patch, zinc plated	1783C
2	Washer, offset, chrome plated	6421
3	Acorn nut, 5/16-18, chrome plated	94006-90T
4	Screw, 10-24 x 1/2 inch w/lock patch, zinc plated	2903
5	Cover, brake pedal pad	42147-07
6	Tread	42146-07
7	Mounting plate	44437-04
Items mentioned in text, but not included in kit:		
А	Brake pedal	
HDON		

-J04070 2 of 2