



# INSTRUCTIONS

-J02661

REV. 2011-05-06

## ACCESSORY FOOTBOARD INSERTS

### GENERAL

#### Kit Number

50295-02, 50310-02, 50500093, 50500096, 50549-08, 50627-08, 51011-01, 51017-01, 54187-10, 54196-10,

#### Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of [www.harley-davidson.com](http://www.harley-davidson.com) (English only).

#### NOTE

*Black Footboard inserts 50549-08 and 50627-08 are designed to show signs of wear. Over time the paint will wear off giving a distressed look.*

#### Kit Contents

This kit contains two foot board inserts.

There are no service parts available with this kit.

### INSTALLATION

#### Remove Existing Footboard Inserts

1. Apply liquid dishwashing soap to the footboard insert rubber beads protruding through the bottom of the footboard.
2. Pry the footboard insert out from the top of the footboard to remove the insert.

#### Install New Footboard Inserts

1. Apply liquid dishwashing soap to the new footboard insert rubber beads.
2. Place the footboard insert into position on the footboard. Use a pliers to pull each rubber bead into its footboard hole until the beads protrude through the footboard.
3. Repeat the above steps for the remaining footboard insert.

