



INSTRUCTIONS

-J00207

REV. 2005-05-05

CHOPPED TOUR-PAK PASSENGER BACKREST PAD

GENERAL

Kit Number

Numbers 52031-96, 52032-96, 52033-96, 52519-03, 52898-98, 53074-03, 52435-05, 51635-06

Models

This kit fits motorcycles equipped with Chopped Tour-Paks®.

Kit Contents

Table 1. Kit Contents

Description (Quantity)	Part Number
Backrest pad	Not Sold Separately
Flanged locknuts, 1/4-20 (6)	7716

INSTALLATION

Install the backrest pad on the Tour-Pak as follows:

1. Align the six backrest pad studs with the existing drilled holes in the Tour-Pak.
2. Fasten the backrest pad studs with the six 1/4-20 flanged locknuts included in the kit. Torque the locknuts to 8 ft-lbs (11 Nm).
3. Close the Tour-Pak cover and check for proper backrest alignment.