



INSTRUCTIONS

-J05472

2011-12-07

EZ TOUR-PAK LID CATCH

GENERAL

Kit Number

53000195

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

This kit contains one lockset catch and two screws (part number 3598).

INSTALLATION

NOTE

Do not use an impact tool to remove screws (1). Use an appropriate hand tool to prevent the screws from breaking off during removal.

NOTE

It may be necessary to trim away some liner material. The lockset catch should mount flush with edge of the Tour-Pak and firmly against the Tour-Pak wall with no liner interference.

1. See Figure 1. Remove two screws (1) and the original equipment (OE) Tour-Pak[®] lockset catch (2), spacer and latch. Discard screws.

-J05472



Many Harley-Davidson[®] Parts & Accessories are made of plastics and metals which can be recycled. Please dispose of materials responsibly.

1 / 2

2. Install two screws, new Tour-Pak® lockset catch, spacer and latch to the Tour-Pak. Tighten screws to 2.3–2.8 N·m (20–25 **in-lbs**).
3. See Figure 2. Verify that the lock guide tab (1) is perpendicular to the Tour-Pak lid edge. If it is not, loosen the lockset, align the lock guide and then tighten the lockset.



Figure 1. Original Equipment Tour-Pak Lockset Catch



Figure 2. Lock Guide