



INSTRUCTIONS

-J03635

REV. 2005-05-11

CHROME TOUR-PAK LID TRIM KIT

GENERAL

Kit Number

53887-05

Models

This kit fits 1993 and later Touring models with King or Chopped Tour-Pak.

Kit Contents

There are no Service Parts available with this kit.

INSTALLATION

NOTE

The Tour-Pak lid does not need to be removed to install this kit.

1. Using a 50/50 isopropyl/water solution, thoroughly clean the Tour-Pak lid surface prior to installing the kit. Allow surface to dry completely.
2. See Figure 1. Test the fit of the chrome trim kit prior to removing the adhesive backing.

NOTE

The chrome trim pieces should be installed on the raised area on either side of the recessed center area. For best results, center the chrome trim pieces from front to back and left to right on the raised areas.

The wider end of the trim pieces should point toward the front of the bike and the narrower end toward the rear.

3. Remove the adhesive liner from the back of the chrome trim piece.

NOTE

The ideal temperature should be at least 60°F (16°C) for proper adhesion of the chrome trim piece.

4. See Figure 2. Center and install the chrome trim piece on the raised area of the Tour Pak lid. Apply firm pressure for one minute using a cloth to prevent scratching the chrome trim piece or paint surface.

5. Repeat steps for the other chrome trim piece.

6. Let the adhesive cure for about 24 hours at no less than 60°F (16°C).



Figure 1. Center Chrome Trim Pieces on Tour-Pak Lid



Figure 2. Chrome Tour-Pak Lid Trim Kit