



INSTRUCTIONS

-J06001

2014-04-10

FAT HANDLEBAR KIT

GENERAL

Kit Number

55800386

55800388

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Installation Requirements

Separate purchase and installation of Riser Kit (Part No. 55900067) is required for installation of this kit on your model motorcycle. This is available from a Harley-Davidson dealer.

▲ WARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333a)

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson dealer.

Kit Contents

This kit contains a handlebar .

INSTALLATION

This handlebar installs in the same manner as the original equipment (OE) handlebar. See the service manual to remove and install the handlebar and risers.

▲ WARNING

Be sure that steering is smooth and free without interference. Interference with steering could result in loss of vehicle control and death or serious injury. (00371a)

- Riser Kit (Part No. 55900067) must be installed. Follow the instructions supplied with the riser kit.
- Make sure clutch cable and front brake line do not pull tight when handlebar is turned to left or right fork stops.
- Make sure hand controls do not touch the fuel tank when turned to left or right fork stops.

-J06001



Many Harley-Davidson® Parts & Accessories are made of plastics and metals which can be recycled. Please dispose of materials responsibly.

1 / 1