

# INSTRUCTIONS

-J00333 REV. 10-30-2000

Kit Number 59081-96

### BAR AND SHIELD CHROME FENDER TIP LENS KIT

### General

This kit is designed for installation on the following model motorcycles:

1980 and later FLHT, Electra Glide Standard; FLHR, Road King; FLT; and FLHS

1986 and later FLSTC, Heritage Softail Classic; and FLSTN, Heritage Softail Special.

This kit does not fit FLSTS or FLTR Road Glide motorcycles

Kit contents:

| QTY | PART NO. | DESCRIPTION                     |
|-----|----------|---------------------------------|
| 1   | 59201-96 | Lens, fender tip, front (amber) |
| 1   | 68081-96 | Lens, fender tip, rear (red)    |

### Installation

- 1. Remove stock front (amber) fender tip lens.
- 2. Select amber fender tip lens from kit.
- Place large tab on lens in groove in lower fender tip lamp housing.

### **CAUTION**

In step four, cover the screwdriver blade with tape to prevent scratching lens.

- 4. Place the blade of a small screwdriver in the space between the lens and notch in the upper-center of the lamp housing. Using firm but gentle pressure between the lamp housing and the lens, pry the upper lens tabs down and push the tabs under the housing. Remove the screwdriver blade from the notch.
- Repeat steps one through four on the rear (red) fender tip lens.



# INSTRUCTIONS

-J00333

REV. 10-30-2000

Kit Number 59081-96

## BAR AND SHIELD CHROME FENDER TIP LENS KIT

### General

This kit is designed for installation on the following model motorcycles:

1980 and later FLHT, Electra Glide Standard; FLHR, Road King; FLT; and FLHS

1986 and later FLSTC, Heritage Softail Classic; and FLSTN, Heritage Softail Special.

This kit does not fit FLSTS or FLTR Road Glide motorcycles.

Kit contents:

| QIY | PART NO. | DESCRIPTION                     |
|-----|----------|---------------------------------|
| 1   | 59201-96 | Lens, fender tip, front (amber) |
| 1   | 68081-96 | Lens, fender tip, rear (red)    |

### Installation

- Remove stock front (amber) fender tip lens.
- 2. Select amber fender tip lens from kit.
- 3. Place large tab on lens in groove in lower fender tip lamp housing.

### CAUTION

In step four, cover the screwdriver blade with tape to prevent scratching lens.

- 4. Place the blade of a small screwdriver in the space between the lens and notch in the upper-center of the lamp housing. Using firm but gentle pressure between the lamp housing and the lens, pry the upper lens tabs down and push the tabs under the housing. Remove the screwdriver blade from the notch.
- Repeat steps one through four on the rear (red) fender tip lens.