



INSTRUCTIONS

-J02629

REV. 11-6-03

Kit Number 60491-02A

CHROME DEBRIS DEFLECTOR COVER FOR TOURING MODELS

General

This kit is designed for installation on all 1997 and later Touring Model Motorcycles.

NOTE

The chrome debris deflector cover mounts over the existing deflector.

Kit Contents

Qty	Description
1	Cover, debris deflector, chrome

Installation

1. Remove left side saddlebag.
2. Remove the stock debris deflectors two *rear* screws. Save screws for installation.
3. Slide the debris deflector cover over the stock debris deflector making sure the lower edge of the deflector is inserted into the edge clip of the cover.
4. Install the two screws saved from Step 2. Tighten securely.
5. Make sure that debris deflector cover does not contact the drive belt, tire or wheel. If necessary, loosen the mounting screws and reposition for clearance.



INSTRUCTIONS

-J02629

REV. 11-6-03

Kit Number 60491-02A

CHROME DEBRIS DEFLECTOR COVER FOR TOURING MODELS

General

This kit is designed for installation on all 1997 and later Touring Model Motorcycles.

NOTE

The chrome debris deflector cover mounts over the existing deflector.

Kit Contents

Qty	Description
1	Cover, debris deflector, chrome

Installation

1. Remove left side saddlebag.
2. Remove the stock debris deflectors two *rear* screws. Save screws for installation.
3. Slide the debris deflector cover over the stock debris deflector making sure the lower edge of the deflector is inserted into the edge clip of the cover.
4. Install the two screws saved from Step 2. Tighten securely.
5. Make sure that debris deflector cover does not contact the drive belt, tire or wheel. If necessary, loosen the mounting screws and reposition for clearance.