



FLAMIN' BRAKE PEDAL PAD 7518

FOR FL

FITS: NO DRILLING REQUIRED FOR H-D- DRESSERS, ROAD KINGS, ROAD GLIDE, STREET GLIDE, AND FL SOFTAILS

THESE MODELS WILL REQUIRE DRILLING OF THE BRAKE PEDAL:

KAWASAKI: '96-UP VULCAN 1500, '05-UP VULCAN 1600 CLASSIC, ALL VULCAN 2000, '06-UP VULCAN 900 CLASSIC

SUZUKI: '05-UP BOULEVARD C 50, '98-'04 INTRUDER 1500LC

YAMAHA: '99-UP ROAD STAR

PARTS INCLUDED

- 1 Flamin' Brake Pedal Pad
- 1 Flame Casting
- 1 Hardware Kit, Including:
 - 1 3/8-16 x 7/8" Hex Bolt
 - 1 3/8-16 Acorn Nut
 - 1 3/8" Flat Washer
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, combination wrenches or socket set and ratchet, needle nose pliers, 3/8" drill bit and drill (depending on model or if motorcycle is equipped with Kuryakyn Forward Controls (P/N 9068, 9069, 9063 and 9064).

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

ALL H-D AND METRICS WITH HOLES IN THE BRAKE PEDALS

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Remove the stock brake lever cover. Peel the rubber off the lever or remove the acorn nut and washer. Set the cover and hardware aside, it will not be reused.

STEP 3 Slide the Flamin' Brake Pedal cover (without rubber pad) over the brake lever and align the hole that applies to your applications. See PIC. 1.

-cont.-

CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



STEP 4 Put the 3/8-16 x 7/8" Hex Head Cap Screw into the brake cover from the top. Reinstall the rubber pad and pull rubber darts through. You may need to use a needle nose pliers to pull the darts completely through. Use a side cutter to remove the excess rubber darts to ensure proper fitment. See [PIC. 2](#).

STEP 5 Tighten the brake cover putting the flat washer on followed by the acorn nut.

STEP 6 Ensure proper clearance and operation before riding the motorcycle.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

METRIC BIKES THAT REQUIRE DRILLING OF THE BRAKE LEVER

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Remove the stock brake lever cover. Peel the rubber off the lever or remove the acorn nut and washer. Set the cover and hardware aside, it will not be reused.

STEP 3 Put the cover in place on your brake lever and mark out the center hole that needs to be drilled.

STEP 4 Use a center punch to mark the exact center of the hole to be drilled. The final bit size needs to be 3/8". You may want to use smaller pilot bits to start out with.

STEP 5 Drill the hole and remove any metal shavings.

STEP 6 Put the 3/8-16 x 7/8" Hex Head Cap Screw through the top of the brake cover and through the hole you just drilled. Reinstall the rubber pad and pull rubber darts through. You may need to use a needle nose pliers to pull the darts completely through. Use a side cutter to remove the excess rubber darts to ensure proper fitment. See [PIC. 2](#).

STEP 7 Install the brake cover on to the brake lever and secure it with the washer and acorn nut.

STEP 8 Ensure proper clearance and operation before riding the motorcycle.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Ride On!

PIC. 1



PIC. 2

