



INSTALLATION

CRUISE ARM MARK III

7914

PARTS INCLUDED

- 1 Cruise Arm Mark III — Left—without Peg
- 1 Cruise Arm Mark III — Right—without Peg
- 2 Mark III Top Plates
- 1 Hardware Kit Including the Following:
 - 8 3/8"-16 x 1" Flat Socket Cap Screws—FSCS — Bright, Stainless Steel
 - 8 3/8" I.D. Thin Flat Washers — Bright, Stainless Steel
 - 8 3/8"-16 Nylock Nuts — Bright, Stainless Steel
 - 2 1/2" I.D. Thin Flat Washers — Bright, Stainless Steel
 - 2 1/2"-20 Nylock Nuts — Bright, Stainless Steel
 - 4 Tubes of Anti-seize
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

CAUTION

This indication alerts you to the fact that ignoring the contents described herein can result in potential injury.

NOTICE

IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.

TOOLS SUGGESTED

Drill with 25/64" bit, Set of Hex Wrenches, Set of Combination Wrenches, Soapy Water Solution.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING

YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

NOTE: '84-'08 TOURING MODELS REQUIRE SUPPORT KIT, P/N 4533, SOLD SEPARATELY. NOT COMPATIBLE WITH FAIRING LOWERS.

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



kuryakyn.com

STEP 2 Apply soapy water solution on the rubber isolators and carefully pull the rubber pad and the attached rubber isolators free from the foot board base.

STEP 3 See PIC.1. Lay the stiffener plates on the foot board base as shown. Use this plate as a template to mark the position of the mounting holes. Use a scribe or felt tip pen to mark the hole positions. Drill four 25/64" holes at your marks.

NOTICE Ensure that the supplied anti-seize is applied to all threaded fasteners before installation; this will make future removal of the fasteners easier.

STEP 4 Loosely install the stiffener plate using two of the countersunk bolts, flat washers, and Nylock nuts as shown in PIC.2. (Rear two mounting holes at this time).

STEP 5 Place the mounting bracket assembly under the foot board so its mounting holes line up with the forward two mounting holes. Install with similar hardware as used at the rear of the board. See PIC.3 and PIC.4.

STEP 6 Tighten all four mounting bolts securely.

STEP 7 Wet the Isolators with soapy solution and reinstall the rubber pad to the steel foot board body. You may have to carefully pull the rubbers through the holes in the board with pliers. The finished assembly will appear as in PIC.5.

STEP 8 Loosen the cruise arm pivot bolt and adjust the arm to a position comfortable to you. Check for interference with the front fender as the front end is turned through its full range of movement. Grasp the front brake and cycle the suspension while the front end is at full lock; do this for both right and left directions. If any contact occurs, adjust the bar closer to the rider and test again. Be certain that the placement of these pegs does not interfere with accessibility to the vehicles controls. Once the optimum position is found, tighten the bar securely into place.

CAUTION Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

STEP 9 Install the foot pegs and tighten the mounting bolts.

STEP 10 Check the tightness of all fasteners. (This should be done periodically.)

WARNING THIS ASSEMBLY IS ONLY AS STRONG AS THE OEM COMPONENTS IT IS ATTACHED TO. ADDING THIS FOOTREST POSITION CAN INCREASE LEVERAGE ON THE OEM EQUIPMENT. THIS ACCESSORY IS INTENDED AS A FOOT REST ONLY. DO NOT STAND ON, OR APPLY EXCESSIVE FORCE TO THESE PEGS.

WARNING CHECK TO MAKE SURE THAT THERE IS PROPER CLEARANCE WHEN CORNERING. LOSS OF CONTROL OF THE MOTORCYCLE AND SERIOUS INJURY MAY OCCUR IF THE PEG/ARM IS NOT POSITIONED PROPERLY. REPOSITION THE OFFSETS IF NECESSARY SO THAT THERE IS ADEQUATE CORNERING CLEARANCE.

NOTICE It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

