



INSTRUCTIONS

-J04987

REV. 2009-06-05

CHROME MUFFLER MOUNT BRACKET

GENERAL

Kit Number

80871-10

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Additional Parts Required

Separate purchase of two TORCA® clamps is required for proper installation of this kit. See a Harley-Davidson dealer for the correct part number.

WARNING

The rider's safety depends upon the correct installation of this kit. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00308a)

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson Dealer.

Kit Contents

There are no Service Parts available with this kit.

REMOVAL

1. Remove mufflers following the instructions in the service manual. Save the hardware for installation.
2. Discard TORCA muffler clamps.
3. Remove the muffler mount bracket. Discard bracket but save the hardware for installation.

INSTALLATION

1. Install the new muffler mount hardware with the stock hardware. Tighten the hardware following the instructions in the service manual.
2. Install the mufflers with new TORCA clamps. Tighten the hardware following the instructions in the service manual.