



# INSTRUCTIONS

-J05438

REV. 2011-03-25

## HARLEY-DAVIDSON LED FLASHLIGHTS

### GENERAL

#### Kit Number

12700024 - 3AAA Tactical LED Flashlight with Safety Strobe

12700025 - 2AAA Pen Light with Fiber Optic Pointer

#### Kit Contents

This kit contains one LED light with batteries.

### OPERATION

#### CAUTION

**Batteries can explode or leak and cause burn injury, if recharged, disposed of in fire, mixed with a different battery type, inserted backwards or disassembled. Replace all used batteries at the same time. Do not carry batteries loose in your pocket or purse. Do not remove the battery label. Keep batteries away from children. If swallowed, consult a physician at once. (00620b)**

- **OPERATION:** To turn on light, press the switch on the end cap, opposite the lens. If the light has more than one setting, press the switch to advance through each setting. Once all of the settings have been reached, the light will turn off.
- **LOCK-OUT SWITCH:** The lock-out switch protects the batteries from turning on unintentionally. To turn on the

light, rotate the end-cap clockwise as far as possible, and press the switch. To lock-out the switch, rotate the end cap 1-2 turns counterclockwise, until the light will not turn on using the switch.

- **FOCUS CONTROL:** Rotate the head of the light (the end with the LEDs) to adjust the beam from spot to flood.

### MAINTENANCE

**BATTERY REPLACEMENT:** Unscrew the end cap and remove the old batteries. Insert new batteries into the flashlight with the positive (pointed) end of the battery toward the lens. Replace the end cap.

- Use only branded batteries.
- Do not mix old and new batteries, or different brands of batteries.
- Dispose of batteries properly. Do not incinerate batteries or otherwise expose them to heat.

#### CARE and MAINTENANCE:

- Keep the light dry.
- Periodically rub a light coat of petroleum jelly onto the o-ring seals to preserve their life.
- Remove the batteries when storing for a long period of time.

