-J05666 2014-04-12

IMPELLER REAR WHEEL

GENERAL

A WARNING

Install only wheels and installation kits approved for your model motorcycle. Contact a Harley-Davidson dealer to verify fitment. Mismatching wheels and installation kits or installing wheels not approved for your model can cause loss of control, which could result in death or serious injury. (00610c)

Kit Number

40900348, 40900391

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Kit Contents

These kits include the custom wheel only. See Figure 1 and Table 2.

Additional Parts Required

Proper installation of these kits require the separate purchase of the following parts which are available at a Harley-Davidson dealer.

- Wheel Installation Kit (See Table 3 and Table 4 to determine required installation kit.)
- Brake Disc Screws (See Table 1 to determine proper hardware.)
- Wheel Bearing Remover and Installer (94134-09)

Recommended Parts

The following Harley-Davidson Genuine Motor Accessories are recommended for proper maintenance and cleaning:

- Chrome Clean & Shine (93600031 [US] and 93600082 [non-US])
- Glaze Poly Sealant (93600026 [US] and 93600079 [non-US])
- Harley[®] Wheel and Spoke Brush (43078-99)
- Wheel & Tire Cleaner (93600024 [US] and 93600076 [non-US])

▲ WARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333a)

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson dealer.

Table 1. Rear Disc and Sprocket Hardware Fitment

Hardware	Fitment					
Rear Disc Screws (select stock or chrome hardware)						
5 Stock disc screws (43567-92)	All models					
Chrome screw kit (46647-05)	All models					
includes 5 screws						
Rear Sprocket Screws (select						
5 Sprocket screw, stock (3109)	2007 and later Dyna, 2007					
Chrome screw kit (94773-07)	and later Softail, 2007					
includes 5 screws and washers	Touring models					
5 Sprocket screw, stock	2000-2005 Dyna, 2000-					
(3737A)	2006 Softail, 2004-2006					
Chrome screw kit (94773-00A)	Touring models					
includes 5 screws and washers						
5 Sprocket screw, stock (3814)	2008 Touring models					
5 Sprocket screw, stock (3873)	2006 Dyna models					
5 Sprocket screw, stock (3899)	2000-2003 Touring, 2001					
	and later Sportster (except					
	Japanese models)					
5 Sprocket screw, stock (40439-	2002-2006 VRSC and					
01)	2007 VRSCR models					
5 Sprocket screw, stock (4552)	2007 and later VRSC mod-					
	els (except VRSCR and					
	VRSCSE models)					
Rear Sprocket Washers						
5 Sprocket washer, stock	2006 and earlier Dyna,					
(6516HW)	Softail and Touring and					
	2000 and later Sportster					
	models (except Japanese					
	models)					
5 Sprocket washer, stock (7039)	2002 and later VRSC					

INSTALLATION

NOTE

Prior to removing or installing the wheel, the rear brake caliper must be removed.

The cotter pin or spring clip for the axle nut must be replaced. They are available for purchase from your dealer. See your dealer for the correct part number for your model motorcycle.

NOTE

Install pull thru valve stem (4099-87) included in the installation kit. Discard all other valve stems.

- Remove existing rear wheel assembly. Save axle, axle nut, brake disc, and wheel spacers for kit installation. Refer to REAR WHEEL in service manual.
- See Figure 1. Install valve stem assembly (H) on wheel. Refer to TIRES in service manual.

NOTICE

Do not re-use brake disc/rotor screws. Re-using these screws can result in torque loss and damage to brake components. (00319c)

NOTE

The valve stem side of the wheel and machined grooves in the hub face indicate the primary bearing side. Install the primary bearing first using appropriate service manual and WHEEL BEARING REMOVER/INSTALLER.

Assemble wheel installation kit components, stock brake disc, and sprocket to wheel using the appropriate service parts table. Refer to REAR WHEEL in Service Manual. Install rear wheel (1), stock axle, and stock spacers to motorcycle. Refer to REAR WHEEL in service manual.

MAINTENANCE AND CLEANING

Chrome parts must be maintained regularly so that they keep their original shine and luster.

- Clean heavily-soiled wheel surfaces using Wheel & Tire Cleaner, applied with Harley Wheel and Spoke Brush.
- 2. Thoroughly clean chrome with a good quality chrome cleaner, such as Harley Chrome Clean & Shine.
- 3. After cleaning and polishing, seal the finish with a good quality sealer, such as Glaze Poly Sealant.

SERVICE PARTS




Figure 1. Service Parts: Impeller Rear Wheels

Table 2. Service Parts and Wheel Kit Contents

Kit Item Description (Quantity)			Part Number			
40900348,	1	Wheel	Not Sold Separately			
40900391						
	Visual indicator mentioned in text:					
	4	Machined groove (all wheels)				

Table 3. REAR 25mm Bearing Wheel Installation Kit (41456-08C)

	•		•		•						
REAR 25 MM Bearing Wheel Installation Kit (41456-08C)		Item (Quantity Used and Description)									
Fitment	Wheel Size	Α	С	D	E	F	Н		J		
2009 and later FLT without ABS	16 x 5.0 in	2	1	0	0	0	*	*	*		
2009 and later FLT without ABS	18 x 5.0 in	2	1	0	0	0	*	*	0		
2008 VRSCD without ABS	18 x 5.5 in	2	0	0	1	**	*	*	0		
2013 and later FXSB, 2008 and later FXCW/C without ABS		2	0	1	0	0	*	*	0		
2008 and later VRSCAW, VRSCDX and VRSCF without ABS	18 x 8.0 in	2	0	0	1	**	*	*	0		

2/3 -J05666

Table 3. REAR 25mm Bearing Wheel Installation Kit (41456-08C)

REAR 25 MM Bearing Wheel Installation Kit (41456-08C)			Item (Quantity Used and Description)									
Fitment	Wheel Size	Α	С	D	E	F	H		J			
Installation kits are designed to work with many different		Α	Bearii	ng, reg	gular	(2)		9276				
fitments. Contact a Harley-Davidson dealer to verify that the wheel and installation kits are both designed and approved for the motorcycle they		С	Axle s	41349-07								
		D	Axle sleeve						41358-08			
are being installed on.		Е	Axle s	sleeve	43704-08							
NOTES:			Bearii	ng shii	m***			41447	7-08			
* See NOTE above valve installation step in INSTALLATION to determine which valve stem to use for your particular kit. Discard other valve stem(s).			,					43157-83A				
		ı						43206-01				
** See INSTALLATION to determine if shim is required.		J	Valve	stem,	pull t	hru		40999	9-87			
*** Bearing shim installed under primary bearing.				·	•							

Table 4. REAR 25 MM Bearing ABS Wheel Installation Kit (41453-08C)

REAR 25 MM Bearing ABS Wheel Installation Kit (41453-08C)				n (Qı	antit	y Use	d and	Des	cripti	on)		
Fitment	Wheel Size	Α	В	С	D	Е	F	G	Н	ı	J	
2008 FLT with ABS	16 x 3.0 in	1	1	0	1	0	0	1	*	*	0	
2014 and later XL with ABS (except 2014 and later	16 x 3.0 in	1	1	0	1	0	0	1	*	*	0	
[883L)		'	'	U	'	U	U	'				
2009 and later FLT with ABS	16 x 5.0 in	1	1	1	0	0	0	0	*	*	*	
2009 and later FLT with ABS	18 x 5.0 in	1	1	1	0	0	0	0	*	*	0	
2008 VRSCDa with ABS	18 x 5.5 in	1	1	0	0	1	**	0	*	*	0	
2008 and later VRSCAWa, VRSCDXa, VRSCXa	18 x 8.0 in	1	1	0	0	1	**	0	*	*	0	
and VRSCFa with ABS		'	'	U	U	'		U				
Installation kits are designed to work with many different wheel		Α	Bearing, regular							9276		
styles and fitments. Contact a Harley-Davidson dealer to verify that			Bearing, ABS**							9252		
the wheel and installation kits are both designed and approved for		С	Axle sleeve							41349-07		
the motorcycle they are being installed on.		D	Axle sleeve							41900-08		
NOTES:		Е	Axle sleeve							43704-08		
* See NOTE above valve installation step in INSTALLATION to		F	Bearing shim***							41447-08		
determine which valve stem to use for your particular kit. Discard		G	Bearing shim***							43904-08		
other valve stem(s).		Н	Valve stem, short 43							4315	7-	
** Primary bearing. Bearing must be installed with red side facing			83A									
the wheel.			Valve stem, long							43206-01		
*** Bearing shim installed under primary bearing.		J	Valve stem, pull thru						40999-87			

-J05666 3 / 3