



INSTRUCTIONS

-J05466

REV. 2011-05-20

CHISEL FRONT BRAKE ROTOR KIT

GENERAL

Kit Numbers

41500040, 41500042

Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

Additional Parts Required

Loctite® 243 Threadlocker and Sealant (Blue) (Part No. 99642-97) is required for installation of this kit. Loctite is available from a Harley-Davidson dealer.

Kit Contents

Table 1. Kit Contents

Item	Description	Part Number
1	Kit 41500040 Front brake rotor, polished	Not Sold Separately
	Kit 41500042 - Front brake rotor, unpolished	41300019
2	TORX® shoulder bolt, chrome (7)	12600056
3	Spring washer (7)	6966M

INSTALLATION

1. Refer to the service manual for brake disc removal and disassembly procedures.

NOTICE

Do not re-use brake disc/rotor screws. Re-using these screws can result in torque loss and damage to brake components. (00319c)

2. Apply Loctite 243 Threadlocker and Sealant (blue) to the threads of the new screws from the kit. Install the brake disc using **ONLY** the new screws.
3. Tighten screws to 25-32 ft-lbs (33.9-43.4 Nm).
Allow Loctite to cure according to the manufacturer's recommendations.

NOTE

Avoid hard stops for the first 300 miles. Hard stops during wear-in period will gall brake discs.

