

# FRONT ANARCHY WHEELS

### GENERAL

# 

Install only wheels and installation kits approved for your model motorcycle. Contact a Harley-Davidson dealer to verify fitment. Mismatching wheels and installation kits or installing wheels not approved for your model can cause loss of control, which could result in death or serious injury. (00610c)

#### **Kit Number**

55128-11, 55066-11

#### Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

#### NOTE

Accessory hub caps are not compatible with this wheel.

#### **Kit Contents**

See Table 1 for kit contents.

#### **Additional Parts Required**

Proper installation of this kit requires the separate purchase of the following parts which are available at a Harley-Davidson dealer:

- Wheel Installation Kit (See Table 2 and Table 3 to determine required installation kit.)
- 2 Brake Discs, stock (44553-06A) or polished (41500012)
- 10 Brake Disc Screws (3762M) and washers (6966M) for stock brake discs (hardware already included in polished rotor kits (41500012))
- Tire (44026-09A)
- Wheel Bearing Remover and Installer (94134-09)

The following Harley-Davidson Genuine Motor Accessories are recommended for proper maintenance and cleaning:

- Harley<sup>®</sup> Bright<sup>™</sup> Chrome Cleaner (94683-99)
- Harley<sup>®</sup> Glaze<sup>™</sup> Polish and Sealant (99701-84)
- Harley<sup>®</sup> Wheel and Spoke Brush (43078-99)
- Harley-Davidson<sup>®</sup> Wheel and Tire Cleaner (94658-98)
- Harley<sup>®</sup> Preserve<sup>™</sup> Bare Aluminum Protectant (99845-07)

### AWARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333a)

#### NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation and is available from a Harley-Davidson dealer.

### INSTALLATION

 Remove existing front wheel assembly. Save axle, axle nut, brake disc, and wheel spacers for kit installation. Refer to FRONT WHEEL in service manual.

#### NOTICE

Do not re-use brake disc/rotor screws. Re-using these screws can result in torque loss and damage to brake components. (00319c)

#### NOTE

Install short valve stem (43157-83A) included in the installation kit. Discard all other valve stems.

2. See Figure 1. Install valve stem assembly (L) on wheel. Refer to TIRES in service manual.

#### NOTE

Do not use a bearing shim included in the installation kit with this wheel kit.

3. Assemble wheel installation kit components and brake disc(s) to wheel, using the appropriate service parts table. Refer to FRONT WHEEL in service manual.

#### NOTES

Install the primary bearing first using appropriate service manual and WHEEL BEARING REMOVER/INSTALLER.

- The left side of the wheel has DOT markings to identify the primary bearing side.
- Install the wheel so that the valve stem is on the right side of the motorcycle.
- 4. Install front wheel (1), stock axle and stock axle nut. Refer to FRONT WHEEL in service manual.

## MAINTENANCE AND CLEANING

Chrome parts must be maintained regularly so that they keep their original shine and luster.

- 1. Clean heavily-soiled wheel surfaces using Harley-Davidson Wheel and Tire Cleaner, applied with Harley Wheel and Spoke Brush.
- 2. Thoroughly clean chrome with a good quality chrome cleaner, such as Harley Bright Chrome Cleaner.
- 3. After cleaning and polishing, seal the finish with a good quality sealer, such as Harley Glaze Polish and Sealant.



## SERVICE PARTS




Figure 1. Service Parts: FRONT ANARCHY WHEELS (18-inch wheel shown)

Kit	ltem	Description (Quantity)	Part Number
55128-11, 55066-11	1	Wheel	Not Sold Separately

### Table 2. FRONT 25 mm Bearing Wheel Installation Kit (41455-08C)

FRONT 25 mm Bearing Wheel Installation Kit (41455-08C)			ITEM (Quantity Used and Description)								
Fitment	Wheel Size	Α	С	D	J	κ	L	М	N		
2008 Touring; 2009 and later FLHRC (non-ABS)	16 x 3.0 in	2	0	4	0	٦	*	*	0		
2009 and later Touring (non-ABS) 17 x 3.0 i			0	1	0	0	*	*	*		
2008 and later Touring (non-ABS)	18 x 3.5 in	2	0	1	0	**	*	*	*		
2008 and later Dyna (except FXDWG and FXDF)	19 x 2.5 in	2	1	0	**	0	*	*	0		
2008 and later VRSCAW, VRSCD, VRSCF and VRSCDX (non-ABS)	19 x 3.0 in	2	1	0	1	0	*	*	0		
2009 and later Touring (non-ABS)	19 x 3.5 in	2	0	1	0	0	*	*	*		
Installation kits are designed to work with many different wheel styles and fitments. Contact a Harley-Davidson dealer to verify that the wheel and installation kits are both designed and approved for the motorcycle they are being installed on. NOTES: * See NOTE above valve installation step in INSTALLATION to determine which valve stem to use for your particular kit. Discard other valve stem(s). ** See NOTES for your wheel kit above the wheel assembly step in INSTALLATION to determine if bearing shim is used for your particular wheel kit and fitment. *** Bearing shim installed under the primary bearing.			A Bearing, regular (2)					9276			
			Axle	41748-08							
			Axle	41900-08							
			Bea	41450-08							
			Bea	43903-08							
			Valv	43157-83A							
		М	Valv	e ste	m, lo	ng	432	06-0	)1		
		N	Valv thru		m, pi	JII	409	99-8	7		

FRONT 25 mm Bearing ABS Wheel Installation Kit (41454-08B)			ITEM (Quantity Used and Description)									
Fitment	Wheel Size	Α	В	С	D	J	κ	L	М	Ν		
2008 Touring and 2009 and later FLHRC with ABS	16 x 3.0 in	1	1	0	1	0	1	*	*	0		
2009 and later Touring with ABS 17 x 3.0		1	1	0	1	0	0	*	*	*		
2008 and later Touring with ABS	18 x 3.5 in	1	1	0	1	**	**	*	*	*		
2008 and later VRSCAW, VRSCD, VRSCF and VRSCDX with ABS	19 x 3.0 in	1	1	1	0	**	**	*	*	0		
2009 and later Touring with ABS	19 x 3.5 in	1	1	0	1	0	0	*	*	*		
Installation kits are designed to work with many different wheel styles and fitments. Contact a Harley-Davidson dealer to verify that the wheel and installation kits are both designed and approved for the motorcycle they are being installed on. NOTES: * See NOTE above valve installation step in INSTALLATION to determine which valve stem to use for your particular kit. Discard other valve stem(s). ** See NOTES for your wheel kit above the wheel assembly step in INSTALLATION to determine which bearing shim to use for your particular wheel kit and fitment. *** Red side of bearing must be installed toward the wheel. The ABS bearing is primary. **** Bearing shim installed under the primary bearing.			Bearing, regular 9276									
			Bea	ABS		9252						
			Axle sleeve					41748-08				
			Axle sleeve					41900-08				
			Bearing shim****					41450-08				
			Bearing shim****						43903-08			
			Valve stem, short						43157-83A			
			Valve stem, long 4						43206-01			
			Valve stem, pull thru					40999-87				

