

PRIMARY COVER CHROME HARDWARE KIT

GENERAL

Kit Number

94052-03A

Models

For model fitment information, please see the P&A Retail Catalog or the Parts and Accessories section of www.harleydavidson.com.

AWARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333a)

NOTE

A Service Manual for your model motorcycle is available from a Harley-Davidson Dealer.

Kit Contents

See Figure 1 and Table 1.

INSTALLATION

AWARNING

To prevent accidental vehicle start-up, which could cause installing. death or serious injury, disconnect negative (-) battery cable before proceeding. (00048a)

AWARNING

Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00049a)

- 1. Disconnect the negative (-) battery cable from the battery. Disconnect the positive (-) battery cable from the battery.
- 2. Follow the procedure found in the Service Manual to remove the hardware from the outer primary cover, inspection cover and clutch cover.
- 3. Consult the Service Manual for screw locations, torque values and recommended gasket replacement.

AWARNING

Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)

4. Connect the positive (-) battery cable to the battery. Connect the negative (-) battery cable to the battery.

NOTE

Items 4 and 5 in the Service Parts table are shipped with LOCTITE[®] Threadlocker applied. If replacement screws are ordered, apply LOCTITE Threadlocker 243 (blue) (Harley-Davidson Part Number 99642-97) to the threads before installing.

SERVICE PARTS




Figure 1. Service Parts: Primary Cover Chrome Hardware Kit

Table 1. Service Parts Table

Item	Description (Quantity)	Part Number
1	Washer, chrome, 0.255/0.270 I.D. x 0.415/0.430 O.D. x 0.06 inch thick (15)	94062-03
2	Screw, chrome, button head, TORX [®] , 1/4-20 x 0.56 inch long (5)	94633-99
3	Screw, chrome, button head, TORX [®] , 1/4-20 x 0.75 inch long (4)	94593-98
4	Screw, chrome, 1/4-20 x 1.25 inch long (5)	94315-91TS
5	Screw, chrome, 1/4-20 x 1.50 inch long (5)	94316-91TS

