

# **INSTRUCTIONS**

**-J07064** 2017-03-14

## COOLFLOW™ FAN KIT

#### **GENERAL**

## **Kit Number**

26800120, 26800121, 26800128

#### Models

For model fitment information, see the P&A Retail Catalog or the Parts and Accessories section of www.harley-davidson.com (English only).

## **Installation Requirements**

Installation of this kit requires programming with Digital Technician II to enable the fan. See a Harley-Davidson dealer.

When other accessories are installed to the main harness, an optional Switched Circuit Adapter Harness (part number 69201706) should be used in conjunction with this kit.

#### **A WARNING**

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a Harley-Davidson dealer perform the installation. Improper installation of this kit could result in death or serious injury. (00333a)

#### NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation. One is available from a Harley-Davidson Dealer.

## **Kit Contents**

See Figure 7 and Table 1.

#### **PREPARE**

#### **WARNING**

When installing any electrical accessory, be certain not to exceed the maximum amperage rating of the fuse or circuit breaker protecting the affected circuit being modified. Exceeding the maximum amperage can lead to electrical failures, which could result in death or serious injury. (00310a)

#### NOTE

Running amperage should be 4 A.

- 1. Remove seat. See service manual.
- 2. Remove right side cover. See service manual.
- Remove right side mid-frame deflector, if equipped. See service manual.

- 4. Remove top caddy. See service manual.
- 5. Remove battery. See service manual.
- Remove charcoal canister, if equipped. See service manual.
- 7. See Figure 1. Locate the fan connector (1) and unplug.

#### NOTE

- When repositioned, the right spark plug wire boots (3) on the coil pack should be facing toward the left side of the vehicle.
- See Table 1. There are holes in the frame to support the use of Christmas tree cable straps (12) to help properly route a wire harness or secure spark plug wires.
- When routing the spark plug wires (2) make sure there is enough clearance between the frame and engine assembly.
- 8. See Figure 1. Reposition right side spark plug wire boots.
  - a. Remove cable straps from wires and frame.
  - Rotate top spark plug boot (3) toward the left side of the vehicle.
  - c. Rotate bottom spark plug boot (3) toward the left side of the vehicle.
  - d. Reroute wires. Install cable straps (2) as needed.




Figure 1. Fan Connector

## **INSTALLATION**

 See Figure 7. If previously equipped, install new mid-frame deflector (13).  Refer to Figure 2.. Position the fan assembly. From within the battery tray area, install the screws (1), lockwasher (2) and flatwashers (3). Tighten to:

Torque: 16.3 N·m (12.0 ft-lbs)





Figure 2. Position the Fan

- 3. Air-Cooled engine only: Install rear oil line hose cover.
  - a. See Figure 3. Reposition plug wire(s), if needed.
  - b. Release upper oil line hose spring clamp (1) and remove upper oil line hose only from head.
  - c. Remove oil line hose spring clamp (1) from hose.
  - Insert cover over rear oil line hose (2). Position cover 25.4 mm (1 in) from upper spring clamp on rear oil line hose.
  - e. Install spring clamp onto oil line hose and install oil line hose onto head.
  - f. With spring clamp loose, rotate hose for maximum clearance between the fan housing and the oil line hose cover (3).




- 1. Spring clamp
- 2. Oil line cover
- 3. Clearance

Figure 3. Rear Oil Line Cover

#### NOTE

See Figure 5. Install optional Switched Circuit Adapter Harness if more than one accessory must be connected between the vehicle P&A connector (1) and fan relay harness connector (2).

- 4. See Figure 4 and Figure 5. Connect harness connectors.
  - a. Connect vehicle P&A connector (1) to fan relay harness connector (2).
  - b. Connect fan connector to fan relay harness connector (3).
  - Connect fan relay harness switch circuit connector
    (3) to vehicle connector (A).
  - d. Secure harnesses with cable straps provided.



- 1. Vehicle P&A connector [325B]
- 2. Fan relay harness P&A connector [325A]
- 3. Fan connector [318A]
- 4. Relay
- 5. Control switch connector [318B]
- A. Vehicle control switch connector [318A]
- B. Fan assembly

Figure 4.

2 / 6 -J07064




Figure 5. Thermal Comfort Fan Wiring Diagram

5. See Figure 7. Install fan switch.

#### NOTE

Install the switch panel (6) in the left side of dash panel. The fan switch (5) should be installed in the far right slot of the switch panel. Add switch blanks (7) as needed.

- a. **Fairing vehicles:** Install switch panel (6) and fan switch (5). See service manual.
- b. **Non-Fairing vehicles:** See Figure 6. Install nut (8), label (9), and switch (10) in right access hole. Plug in switch to harness which is located under the headlamp nacelle. See service manual.




Figure 6. Non-Fairing Switch Location

- 6. Install charcoal canister, if equipped. See service manual.
- 7. Install battery. See service manual.
- 8. Install top caddy. See service manual.
- 9. Install right side cover.
- Install seat. After installing seat, pull up on the seat to verify that it is secure. See service manual.
- 11. Enable the fan using Digital Technician II.

-J07064 3 / 6

12. Perform operations check on fan switch.

## Operation

#### NOTE

Verify that fan is turned OFF before starting the engine. Under certain circumstances, an errant diagnostic trouble code may be set if the engine is started with the fan in the ON or Auto settings. Clear the code.

The fan can be switched to Off/On/Auto operation.

#### · ON setting;

- The fan runs at speeds below 64 km/h (40 mph).
- Fan will stop running at speeds above 64 km/h (40 mph).
- As speed lowers, the fan turns back on at 56 km/h (35 mph). This gap prevents the fan from cycling on and off during low speed changes.

 AUTO setting: The fan operates based on a combination of vehicle speed, engine temperature and ambient air temperature.

#### **Vehicles with Ambient Air Sensors**

- i. The fan runs at speeds below 64 km/h (40 mph) when the engine temperature is above 95 °C (203 °F) and ambient air temperature is above 15 °C (59 °F).
- ii. The fan runs at speeds below 64 km/h (40 mph) when the engine temperature is above 215 °C (419 °F) and ambient air temperature is below 15 °C (59 °F).
- iii. Fan turns off if vehicle speed exceeds 72 km/h (45 mph) or if engine temperature goes below this temperature 202 °C (395 °F).

## · Vehicles without Ambient Air Sensors

- The fan runs at speeds below 64 km/h (40 mph) when the engine temperature is above 95 °C (203 °F).
- Fan turns off if vehicle speed exceeds 72 km/h (45 mph) of if engine temperature goes below this temperature 82 °C (179 °F).

4/6 -J07064

## **SERVICE PARTS**




Figure 7. Service Parts: Fan Kit

**Table 1. Service Parts Table** 

Kit	Item	Description	QTY	Part Number
Kit 26800120	1	Screw, button head	2	4365
	2	Lockwasher	2	7036
	3	Washer, flat	2	6703
	4	Fan assembly	1	26800096
	5	Switch, fan, momentary	1	71400121
	6	Dash panel base	1	69200173
	7	Switch, dash, blank	2	71400031
	11	Cable strap	3	10006
	12	Cable strap	2	10287
	13	Harness, thermal comfort fan with relay	1	69201705
	15	Clip, spark plug	2	10120
	16	Cover, oil line	1	62700220

-J07064 5 / 6

**Table 1. Service Parts Table** 

Kit	Item	Description	QTY	Part Number
Kit 26800121	1	Screw, button head	2	4365
	2	Lockwasher	2	7036
	3	Washer, flat	2	6703
	4	Fan assembly	1	26800096
	8	Nut, satin chrome	1	74408-08A
	9	Label, fan switch	1	1400100
	10	Switch, fan, momentary	1	71400122
	11	Cable strap	3	10006
	12	Cable strap	2	10287
	13	Harness, thermal comfort fan with relay	1	69201705
	15	Clip, spark plug	2	10120
	16	Cover, oil line	1	62700220
Kit 26800128	1	Screw, button head	2	4365
	2	Lockwasher	2	7036
	3	Washer, flat	2	6703
	4	Fan assembly	1	26800096
	5	Switch, fan, momentary	1	71400121
	11	Cable strap	3	10006
	12	Cable strap	2	10287
	13	Harness, thermal comfort fan with relay	1	69201705
	14	Deflector, mid-frame	1	57200151
	15	Clip, spark plug	2	10120
	16	Cover, oil line	1	62700220

6 / 6 -J07064