



INSTRUCTIONS

-J02831

REV. 10-6-2004

Kit Number 50631-04

OPERATOR FOOTBOARD KIT

General

This kit is designed for use on 1986 and later FLHR/I/CI, FLHT/C/CI/CUI, FLST/N/S/SI/F/FI/C/CI and FLTR/I models.

This kit is not compatible with Leather Rider Footboard Fringe Kit 50205-97 or 50206-98.

This kit contains the following items:

| QTY | DESCRIPTION | PART NO. |
|-----|-----------------------------------|---------------------|
| 1 | Footboard assembly (right) | Not sold separately |
| 1 | Footboard assembly (left) | Not sold separately |
| 4 | Shoulder bolt, 1/4-20 x 1-3/32 in | 50635-82B |
| 4 | Locknut, flanged, 1/4-20 | 7716 |

Footboard Installation

1. Remove and discard the two hinge bolts and locknuts attaching the existing footboard to the mounting brackets, and remove the footboard.
2. Clean and inspect the footboard brackets, and replace if worn, rusted or damaged.


3. Set the correct footboard (see Figure) in place over the mounting brackets. Line up the holes and install the shoulder bolts and locknuts from the kit. Torque to 7-9 ft-lbs (9-12 Nm).

4. Check that the footboard pivots freely on the hinge bolts.

Repeat all procedures for the other side.

NOTE

Avoid contacting chrome surfaces with abrasive materials (stones, sand, etc.) as damage will result.



INSTRUCTIONS

-J02831

REV. 10-6-2004

Kit Number 50631-04

OPERATOR FOOTBOARD KIT

General

This kit is designed for use on 1986 and later FLHR/I/CI, FLHT/C/CI/CUI, FLST/N/S/SI/F/FI/C/CI and FLTR/I models.

This kit is not compatible with Leather Rider Footboard Fringe Kit 50205-97 or 50206-98.

This kit contains the following items:

| QTY | DESCRIPTION | PART NO. |
|-----|-----------------------------------|---------------------|
| 1 | Footboard assembly (right) | Not sold separately |
| 1 | Footboard assembly (left) | Not sold separately |
| 4 | Shoulder bolt, 1/4-20 x 1-3/32 in | 50635-82B |
| 4 | Locknut, flanged, 1/4-20 | 7716 |

Footboard Installation

1. Remove and discard the two hinge bolts and locknuts attaching the existing footboard to the mounting brackets, and remove the footboard.
2. Clean and inspect the footboard brackets, and replace if worn, rusted or damaged.

3. Set the correct footboard (see Figure) in place over the mounting brackets. Line up the holes and install the shoulder bolts and locknuts from the kit. Torque to 7-9 ft-lbs (9-12 Nm).

4. Check that the footboard pivots freely on the hinge bolts.

Repeat all procedures for the other side.

NOTE

Avoid contacting chrome surfaces with abrasive materials (stones, sand, etc.) as damage will result.

