



## TURN SIGNAL MIRRORS

# 1432

### PARTS INCLUDED

- 1 Left Side Turn Signal Mirror Assembly with Convex Glass
- 1 Right Side Turn Signal Mirror Assembly with Convex Glass
- 1 Hardware Kit, Including:
  - 2 5/16"-18 X 1-1/2" Socket Head Cap Screws
  - 2 5/16"-18 X 2" Socket Head Cap Screws
  - 1 2.5mm Hex Key Wrench
  - 2 5/16" Split Lock Washers
  - 2 5/16" Internal Tooth Lock Washers
  - 2 Double End Threaded Studs
- 1 Load Equalizer with Three Scotch Lock Connectors
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.**



**THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.**



**This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.**



**This indication alerts you to the fact that ignoring the contents described herein can result in potential injury.**



**IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.**

### TOOLS SUGGESTED

Set of Hex Wrenches, Set of Combination Wrenches

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

### ALL INSTALLATIONS

#### STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

**NOTE:** The included 2.5mm Hex Wrench is used only in P/N 1428, 1430, 1437 & 1438 to adjust the swivel ball tension.

**NOTE:** Mirror adapters (sold separately) are required for installation on metric cruisers.

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - The product must be properly installed, maintained and operated under normal conditions.
  - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
  - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



**WARNING**

A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

**NOTICE**

The Turn Signal Mirrors are intended to be used as supplemental lighting only. Any other use may be in violation of Federal, State or local regulations.

**NOTICE**

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.


**NOTICE**

Ensure that the position of the mirror and stem DO NOT interfere with the operation of the motorcycle hand controls.

**NOTICE**

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners

FIG 1



**STEP 2**

Remove the stock mirrors from controls; set them aside, they will not be re-used.

**MOUNTING WITH SINGLE SCREW**

**STEP 3**

Determine which of the included socket head cap screws from the hardware kit will provide maximum thread engagement in the mirror stem without bottoming out.

**STEP 4**

Place a split lock washer over the socket head cap screw and insert it in the hole in the hand control. FIG 1

**STEP 5**

Place an internal lock washer over the protruding end of the cap screw.

**STEP 6**

While holding the mirror in place, thread the socket head cap screw into the bottom of the mirror stem.

**NOTE:** Ensure that the setscrew in the mirror stem does not prevent the socket head cap screw from being installed fully. FIG 1

**STEP 7**

Adjust the position of the mirror stem for visibility and clearance; tighten the socket head cap screw and then the setscrew.

**STEP 8**

Adjust the mirrors for proper view before riding the motorcycle.

-cont.-

**STEP 9** Repeat STEP 3 through STEP 7 for the opposite side.

**H-D with Bottom Mounted Turn Signals—Right Side Procedure**

**CAUTION** Removing the retainer nut and/or the ball stud clamp in the next Step will release the turn signals from the hand controls. Secure the turn signals to prevent damage or injury.

**STEP 10** Loosen and remove the retainer nut and ball stud clamp shown in FIG 2

**STEP 11** Remove the stock mirror; hold the stock turn signal to prevent it from being damaged.

**STEP 12** Screw a double ended stud into the new mirror stem; tighten and then tighten the set screw. FIG 2

**NOTE:** Ensure that the setscrew in the mirror stem does not prevent the double ended stud from being installed fully. FIG 2

**STEP 13** Place an internal lock washer over the long end of one of the double-ended studs; insert the assembly into the mirror stem hole in the hand control. FIG 2

**STEP 14** Place a split lock washer over the protruding end of the double-ended stud and thread the retainer nut onto the stud. FIG 2

**STEP 15** Adjust the position of the mirror stem for visibility and clearance; tighten the retaining nut.

**STEP 16** Install the ball stud clamp onto the retainer nut; adjust the turn signal and tighten the clamp.


**STEP 17** Repeat STEP 3 through STEP 7 for the LEFT SIDE.

**STEP 18** Adjust the mirrors for proper view before riding the motorcycle.

**WIRING THE MIRRORS**

**STEP 19** Identify the stock turn signal wiring harness; refer to your factory service manual to locate the harness.

**STEP 20** Turn the key "ON" and using a test light or the wiring diagram for your bike, determine a "keyed" 12 volt power wire (one that has power when the key is on and loses power when the key is off), left and right turn signal power and a ground wire. Label each of these wires for their function or write the color and function down. Turn the key "OFF" and disconnect the battery.



-cont.-

**CAUTION** Avoid potential electrical shock! Be sure to disconnect the battery before starting this procedure.

**STEP 21** Attach the **RED** wire from each Mirror to the “**keyed**” power wire located in Step 19. Attach the **WHITE** wire from each Mirror to the correct **turn signal** (left to left—right to right) power wire located in Step 19. Connect the **BLACK** wires from each Mirror to the **GROUND** wire located in Step 19. FIG 3 Carefully insulate your splices and secure the wiring away from any pinch points or excessive heat.

**NOTICE** Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

**STEP 22** Reconnect the battery, start the bike and test all lights. If the turn signals flash erratically, install the included load equalizer as directed in the following Steps.



**WARNING** ENSURE PROPER LIGHT OPERATION BEFORE RIDING THE MOTORCYCLE. VISIBILITY IS A MAJOR CONCERN FOR MOTORCYCLISTS. A LIGHTING MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY.

**CAUTION** Always install the load equalizer upstream of any existing aftermarket multifunction control modules. Do not install a load equalizer between a module and the turn signals as this will overload the module. Overloading will damage the module and may create a fire hazard!

**CAUTION** Load equalizers generate heat when in use. Avoid using the turn signals for an extended period of time, otherwise the load equalizer will over heat. Never operate the four-way flashers unless you first remove the load equalizer. Overheating damages the load equalizer causing loss of turn signal operation and could create a fire hazard!

**STEP 23** **If the bike IS NOT equipped** with a Küryakyn controller of any sort, locate the left and right turn signal power wires and a ground wire on the bike’s wiring harness using a test light or wiring schematic for your model, typically easiest access is beneath the seat or behind a side cover. Disconnect the battery, cut off the 3-pin connector of the load equalizer. Using the included Scotch Locks, connect one **VIOLET** wire from the load equalizer to the **RIGHT** turn power wire and the other **VIOLET** wire from the load equalizer to the **LEFT** turn power wire. Connect the black wire from the load equalizer to the **GROUND** wire. FIG 4

**If the bike IS equipped** with a Küryakyn Panacea Taillight System or Küryakyn Run-Turn-Brake Controller, simply plug the load equalizer into an unused 3-pin connector on the module. If there aren’t any unused 3-pin connectors on the module, cut off the connector of the load equalizer and using the included Scotch Locks, splice the wires to the like-colored wires on the load equalizer already in place.



**STEP 24** Load equalizers generate heat when in use; secure the load equalizer away from any heat sensitive components. We recommend securing the load equalizer to the bike frame as this will act as a heat sink, helping to cool the load equalizer.

**NOTICE** Do not secure the load equalizer to the control module! Excess heat from the load equalizer could damage the control module.

**STEP 25** Reconnect the battery, start the bike and test all lights.

**WARNING** ENSURE PROPER LIGHT OPERATION BEFORE RIDING THE MOTORCYCLE. VISIBILITY IS A MAJOR CONCERN FOR MOTORCYCLISTS. A LIGHTING MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY.

**STEP 26** Replace the seat and/or side cover if removed.

**WARNING** AFTER INSTALLING THE SEAT, PULL UP ON IT TO ENSURE IT IS LOCKED INTO PLACE. A LOOSE SEAT CAN SHIFT AND CAUSE LOSS OF CONTROL RESULTING IN SERIOUS INJURY OR DEATH.

**ADJUST SWIVEL BALL TENSION**

**STEP 27** Remove the mirror head from the stem using an open end wrench on the flat on the end of the ball stud to loosen the stud from the stem. PIC 1 Remove the two fasteners from the back of the mirror cover, set aside, they will be reused. PIC 2 Pull the back cover towards the stem, separating the front from the back. PIC 3 Turn the mirror head counterclockwise to remove it from the stem.

**NOTE:** The back of the mirror with the LEDs and wire attached will be loose from the stem. Do not let it fall and damage the housing or bike.

**NOTE:** Make sure the hex wrench is fully seated in the bolt before you try to move the two bolts. Improper fitting wrenches will strip the head on these bolts!

**STEP 28** Turn the tension screws inside the mirror head to increase or decrease the tension on the ball joint. Turn the screws clockwise to increase tension; turn the screws counter-clockwise to decrease tension. Place a drop of light lube (WD-40) on ball. PIC 4

**STEP 29** Replace the front of the mirror by installing the threaded end of the ball stud through the back of the mirror housing and threading it clockwise to the stem. Replace the two fasteners removed in STEP 27 that secure the front to the back of the mirror head. Tighten all fasteners.

**NOTICE** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

