LOW PROFILE ECE L.E.D. TAILLIGHT, RED WITH LICENSE ILLUMINATION   5466

Thank You For Choosing Küryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

⚠ **WARNING**	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

**ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:**

1   **Deluxe ECE L.E.D. Taillight**

     1   **Adapter Kit Containing**

         1   **"Bulb-Style" Adapter**

         1   **"Plug-In-Style" Adapter**

         1   **Dielectric Grease Packet**

     1   **Taillight Gasket with Adhesive Back**

YOU WILL ALSO NEED:

Phillips head screwdriver

NOTICE	These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.
⚠ **WARNING**	THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THESE INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY. ACCIDENTAL VEHICLE START-UP COULD CAUSE DEATH OR SERIOUS INJURY, REMOVE THE MAIN FUSE BEFORE PROCEEDING.
NOTICE	Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

STEP 1   Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. Allow the engine and exhaust system to cool. Remove the main fuse.

STEP 2   Remove the existing taillight; remove the bulb or connector from the taillight base. Only the two screws will be re-used.

NOTICE	Dielectric grease inhibits moisture and prevents corrosion. Kuryakyn recommends the use of the included dielectric grease on ALL electrical connections. Apply dielectric grease directly to mating surfaces.

"Plug-In-Style" adapter plugs into the taillight base in the same manner as the existing taillight and will only fit one way.

"Bulb-Style" adapter installs like a light bulb; push the adapter in and turn it clockwise.

NOTICE — Ensure proper adhesion of this product. Remove all grease, oil, bugs, dirt, and other debris (including wax and polish) from the installation area. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation.

Do not attempt this installation in temperatures below 50°F (10°C). Proper adhesive bonding ONLY occurs above 50°F (10°C).

STEP 3 — Clean the inside of the taillight base.

Remove the paper backing from the adhesive gasket; apply the gasket to the taillight base. The extra flap in the gasket is designed to seal the wire opening in the taillight base. If you normally drive in wet weather, you may want to seal the wire opening with silicone or electrical tape for extra protection.

STEP 4 — Reinstall the main fuse. Test for run and brake light functions with the motorcycle running.

STEP 5 — Turn IGN OFF. Secure the Taillight to the base using the two existing screws. Do not over-tighten.

NOTICE — It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.