

# INSTALLATION

## TRANSMISSION/OIL LINE COVER 8208

FITS: ALL 99-'05 DYNA MODELS

## **PARTS INCLUDED**

- 1 Transmission, Oil Line Shroud
- 1 Hardware Kit Including:
  - 1 1/4"-20 x 5/8" Socket Head Cap Screw Chrome
  - 1 1/4"-20 x 1-3/4" Socket Head Cap Screw Chrome
  - 2 .267 x .423 x .008 Wave Washer
  - 2 .250 x .428 x .062 Flat Washer Chrome
  - 2 1/4" Hot Spot Chrome
  - 1 10-24 x 3/8" Socket Head Cap Screw Chrome
  - 1 #10 Stainless Steel Wave Washer
  - 1 .207 x .288 X .045 Flat Washer
  - 1 1-1/8" Long Stand-off Stud
  - 1 1/4"-20 x 1-7/8" Long Stand-off Stud
  - 1 10-24 x 3/8" Button Head Cap Screw Chrome
  - 1 #10 External Tooth Lock Washer
- 1 Installation Instruction

Please read and understand entire instructions before starting installation.

#### THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE

CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR

SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein

can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein

may negatively affect product performance and functionality.

### **TOOLS SUGGESTED**

A Set of Standard Allen Wrenches, Torque Wrench and a 7/16" Open-end Wrench

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

-cont.-

#### **CUSTOMER SERVICE**

877.370.3604 (toll free)

## **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

#### **LIMITED WARRANTY**

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

 Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

• The product must be properly installed, maintained and operated under normal conditions.

· Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

 Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.

> Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.

· Küryakyn electrical products are warranted for one
(1) year from the date of purchase by the consumer.
Components of Küryakyn products containing L.E.D.s
will be warranted for defects in materials and
workmanship for 3 years from the date of purchase.

Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

## **ABOUT OUR CATALOG**

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today–select the "CATALOGS" icon. Each Küryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA All Rights reserved




## **PROCEDURE**

**STEP 1** Remove the stock oil line cover by removing the two fasteners labeled A and B in <u>PIC.1</u>.



- **STEP 2** Install the larger of the two Stand-off Studs where fastener B was previously installed being careful not to over-tighten the Stand-off Stud.
- **STEP 3** Remove the OEM socket head cap screw from the electronic speedometer sensor shown in <u>PIC.2</u>. Replace this fastener with the smaller Standoff Stud being careful not to over tighten.
- **STEP 4** Remove the OEM fastener from the transmission trap door located directly in line with the transmission dipstick labeled as C in PIC.1.
- **STEP 5 OPTIONAL STEP**. Remove the OEM wiring harness hanger from the OEM oil line cover and secure it to the webbed boss on the back side of the new Transmission/oil Line Cover using the supplied 10–24 x 3/8" Button Head Cap Screw and the # 10 External Tooth Lock Washer.
- **STEP 6** Slip the cover into place. The lower portion of the Transmission/oil Line Cover will go behind the clutch cable. These are close quarters so it may take more than one attempt to maneuver the cover into position. The cover will NOT require any bending or twisting to get it in place.
- **STEP 7** Loosely install the supplied  $1/4"-20 \times 5/8"$  Socket Head Cap Screw, Wave Washer (.267 x .423 x .008) and Flat Washer (.250 x .428 x .062), in the front of the cover.
- **STEP 8** Loosely install the supplied  $10-24 \times 3/8$ " Socket Head Cap Screw, #10 Stainless Steel Wave Washer and Flat Washer (.207 x .288 x .045) in the rear of the cover at the electronic speedometer sensor.
- **STEP 9** Loosely install the supplied  $1/4"-20 \times 1-3/4""$  Socket Head Cap Screw, Wave Washer (.267 x .423 x .008) and Flat Washer (.250 x .428 x .062), in the hole in the middle of the cover.
- **STEP 10** Once all three fasteners are loosely installed, go back and tighten the middle fastener to 7–9 foot-pounds and the front and rear fasteners snugly. DO NOT over-tighten the front and rear fasteners.
- **STEP 11** Push the supplied Hot Spots into the two 1/4" Socket Head Cap Screws visible on the face of the cover.
- **STEP 12** If you opted to re-install the OEM wiring harness hanger in STEP 5, lift the wiring harness into the hanger using a screwdriver or similar length tool from underneath the motorcycle.







**PAGE 2**